

INSTALLATION INSTRUCTIONS

N9314

READ AND SAVE THESE INSTRUCTIONS

WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER.
AVERTISSEMENT! COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DU DISJONCTEUR.

PREPARING THE FIXTURE (Fig. 2)

1. Carefully unpack the new fixture and lay out all the parts on a clear area. Take care not to lose any parts necessary for installation.
2. Shut off the power at the fuse box or circuit breaker. If necessary, remove the old fixture including the mounting hardware.

MOUNTING THE FIXTURE (Fig.1)

3. The mounting strap contains several pairs of threaded holes, find the pair of holes that match the hole spacing on the lamp cover and thread two lamp screws into the mounting strap and tighten with a hex nut. Note: The length of the fixture screw on the mounting strap can be adjusted if necessary.
4. Attach the mounting strap to the ceiling with screws. The side of the mounting strap marked "GND" must face out.

CONNECTING THE WIRES (Fig. 3)

5. At this point, connect the electrical wires as shown in Fig. 3, making sure that all wire (green or bare copper), connect the fixture's ground wire directly to the mounting strap using the green screw provided.
6. Tuck wire connectors neatly into outlet box.

FINISHING THE INSTALLATION (Fig. 2)

7. Separate the mounting strap (G) by removing the screws (F). Install the mounting strap (G) on the ceiling and reattach the light fixture to it with the screws (F).
8. Unscrew the screws (D) and remove the base (E) to place the arms (A).
9. Insert the arms (A) through the holes in the plate (F), securing them with the washer (C) and the nut (B). Repeat this step for all arms.
10. Replace the base and screw the screws (D) back into the base (E) and plate (F).

DO NOT EXCEED THE MAXIMUM WATTAGE RATING!
(NE PAS DEPASSER LA PUISSANCE NOMINALE MAXIMALE!)

Your installation is now complete. Return power to the outlet box and test the fixture.

IMPORTANT: For a safe and secure installation, these fixtures must be installed by means of supports that are independent of the outlet box. (Note - For heavy fixtures hickey and cable lock are provided, other required hardware to be supplied by installer)

Note: Illustration on this manual is for installation purposes only. It may or may not be identical to the fixture purchased. Do not clean your light fixture or parts with water or cleanser.

