

INSTALLATION INSTRUCTIONS FOR P5546-66A-L

For LED Flush Mount

READ AND SAVE THESE INSTRUCTIONS

WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER
AVERTISSEMENT! COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DO DISJONCTEU

ASSEMBLING THE FIXTURE (Fig.1)

1. Shut off power at the fuse box or circuit breaker box and remove the old fixture including the mounting hardware.
2. Carefully unpack your new fixture and lay out all the parts in a clear area. Take care not to misplace any small parts necessary for installation.
3. Position mounting plate (A) on the ceiling and mark the location of three drywall anchors (D). Pre-drill holes for drywall anchors (D). Then insert drywall anchors (D) into the ceiling.
4. Attach mounting plate (A) to junction box (not included) using mounting screws (B) (Size: 8-32*1/2"L). The side of mounting plate (A) marked "GND" must face out.
5. Place wood screws (E) through the holes of mounting plate (A) and into drywall anchors (D) to secure mounting plate (A) to the ceiling.

CONNECTING THE WIRES (Fig.2)

6. Connect the electrical wires as shown in Fig.2, making sure that all wire connectors are secured. If your junction box has a ground wire (green or bare copper), connect fixture's ground wire to it. Otherwise, connect the fixture's ground wire directly to mounting plate (A) using green screw (C) provided.

COMPLETING THE INSTALLATION

7. Align canopy (F) onto mounting plate (A) and secure with screws (G).
8. Adjust LED disc (H) to desired angle.

Your installation is now complete. Return power to the junction box and test the fixture.

CAUTION /ATTENTION: When handling fixture, do not apply pressure to LEDs. Hold fixture by the base only.

IMPORTANT: Fixture should be installed by a qualified electrician to ensure proper wiring and installation.
Dimmable with ELV and/or LED compatible wall dimmer switches.

Fig.1

Set#: A-021-409

Mounting plate

Green screw

Wood screw (3)

Drywall anchor (3)

Mounting screw(3)




Fig.2

<p>FIXTURE WIRES Black or Smooth</p>	<p>FIXTURE WIRES WHITE OR RIBBED</p>	<p>FIXTURE WIRES Green or Bare Copper (Ground)</p>
<p>HOUSE WIRES Black (Hot)</p>	<p>HOUSE WIRES White (Neutral)</p>	<p>HOUSE WIRES Green or Bare Copper (Ground)</p>

